

How to replace a door?

It is most important to have at least one other person to help. It is very dangerous to try to replace the door by yourself, without anybody's help the door might fall and the glass might be broken, which is terribly dangerous.

1. Open the door, unscrew the lower hinge which highlight in red.



2. After unscrew the door hinge, take off the door slightly.



3. Assemble the lower hinge on the door.



4. Fix the door and hinge on the unit body, the lower hinge should put against the two holes on the right of bottom grill and twist them.



5. Finish.